



Attach each end of strap to studs with 10g Flat Head screws as per Engineering. After ends are connected each strap must be tensioned with one strap tensioner. Post tension, strap must be screwed to each stud it crosses using 10g Flat Head screws.

Connect to foundation with Screw Anchor or Wedge Anchor, according to manufacturer's specifications.

Strap Brace to Wall Connection

Note: Consult with Engineer for each connection